

# ServoMaster: Metadata: controller/precision

## 1. Definition

`controller/precision` *property* contains the maximum precision this controller is capable of, in number of steps.

Note that this value may not represent the actual precision exactly for example, the precision for the particular servos in [QuadServo](#) and [AdvancedServo](#) will depend on the current `min_pulse` and `max_pulse` settings. In order to retrieve the exact precision, use the [servo/precision](#) *property*.