

ServoMaster: Metadata: servo/velocity

1. Definition

`servo/velocity` *property* contains the currently set servo velocity, in °/sec.

See also [servo/acceleration](#).